

BULK TANK SANTIZING PROCEDURES**PURPOSE**

To ensure the correct washing, sanitization, and cooling procedures of the Bulk tank.

2. RESPONSIBILITY

All trained and qualified personnel.

3. PROCEDURE**3.1 WASH – 44 MINUTES:**

3.2 Make sure the valve at the base of the bulk tank is open.

3.2.1 Rinse the inside of the bulk tank, the underside of the lid and the rubber gasket.

3.2.2 Connect the long thin hose to the washer.

3.2.3 Attach the large hose to the opening of the bulk tank. The large nut must be tight.

3.2.4 On the control panel, turn the switch to “LAVAGE”.

3.2.5 Press the top button “CYCLE DE PRÉ-RINÇAGE”.

3.2.6 Wash the stainless-steel cap and the plastic nut. Place stainless cap on top of plastic nut and leave on the step.

3.3 SANITIZE (just before the next milking) 9 MINUTES:

3.3.1 The switch should already be on “LAVAGE”.

3.3.2 Press the bottom right button “CYCLE D’ASSAINISSEMENT”.

3.3.3 When the sanitize cycle is finished, disconnect the large hose. Leave it on the ground.

3.3.4 Allow the water to drain from the bulk tank before closing the valve.

Document Status and Revision History

DATE	NEW VERSION
7-Nov-2017	Version 02: Macdonald Campus FACC approved
1-June-2023	Version 03: Macdonald Campus FACC approved